


Safety

- ▲ Do not exceed load limit of 80 kg (176 lb).
- ▲ Never leave children on a parked bike unattended.

What's Included

1. Atlas Kickstand
2. Oval Plate
3. Bolt Set x 2



Parts Required (not included)

Chain Guide Pulley Set




GSD S00 owners can obtain the Chain Guide Pulley Set from their Tern dealer. Please check the support site on ternbicycles.com or work with your dealer to install the Chain Guide.

Installation

Tools Required (not included)

1. 17 mm Wrench
2. 8 mm Allen Key
3. Zip Tie
4. Chain Link Open Plier*
5. Chain Link Close Plier*


* GSD S00 requires the use of the chain link pliers.



1. Remove your existing kickstand.


Please check the support site on ternbicycles.com for more information or visit your dealer if you are unfamiliar with how to remove your kickstand.

2. If you have a GSD S10 (equipped with a derailleur), shift to the smallest cog.




3. Position Master Link on the chain between Chain Guide Pulley and Motor.

Attach a zip tie in front of Master Link to prevent chain from falling off the chainring.




4. Use the Open Plier to open Master Link outer plate.


If you are unsure how to complete this step, please visit your dealer.



⚠ Do NOT use a chain-breaking tool.




5. Detatch and open.




Assembly Order


1. Bolt
2. Spring washer
3. Oval Plate
4. GSD
5. Atlas Kickstand
6. Washer
7. Nut




6. Position Oval Plate.




7. Install Bolts and tighten to a torque of 35-40 Nm.



8. Thread chain over Chain Guide.




5. Press both halves of the Master Link connector together and use Master Link Close Plier to lock outer plates into place.



Listen for a 'click'.

Verify the Master Link rotates freely and without stiffness.



LIMITED PRODUCT WARRANTY INFORMATION: This Product comes with a ONE (1) YEAR Limited Warranty from the date of retail purchase by the original end-user. If a material or workmanship defect arises and a valid claim is received within the Warranty Period, this Product will be replaced. Mobility Holdings cannot be held liable for damages to personal property due to misuse or improper care and maintenance. This Product Warranty does not, under any circumstance, cover the replacement or cost of any third party product used with or connected to the Product.

Trademarks are the property of their respective owners. Tern, the Tern Werd (logotype), the Tern Berd (device), Atlas and GSD used alone or in combination are trade names, trade devices or registered trademarks of Mobility Holdings, Ltd.

© 2020 Mobility Holdings, Ltd. All rights reserved.