


Parts


- 1. Suitcase Pad
- 2. Seatpost Sock
- 3. Handlebar Sock (2)
- 4. Handlepost Sock
- 5. Dropout Sock
- 6. Fork Dropout Protector
- 7. Frame Dropout Protector
- 8. Pedal Bag




Tools Required (not supplied)

- 5 mm hex wrench
- 15 mm open wrench (for non-QR pedals or hubs)


Bike Disassembly & Bagging




- 1. Remove Pedals and place in Pedal Bag and set aside.




- 2. Remove Handlepost by first loosening the Handlepost Steerer Bolts and then opening and removing the Top Cap Bolt.




- 3. Replace the Top Cap and Top Cap Bolt after removing the Handlepost.




- 4. Close Handlepost Lever, then slide Handlepost Sock from the base of the Handlepost and fasten in place.
- 5. Slide Handlebar Socks over each side of the Handlebar and fasten in place.




- 6. Remove Seatpost and slide Seatpost Sock on.
- 7. Remove QR Skewers from Wheels, if fitted.
- 8. Remove Wheels, disconnecting any Coaster Brake and/or Gear Cables, if required.



- 9. Slide Dropout Sock over the left Rear Dropout. Ensure the opening faces down.
- 10. Attach Pedal Bag to left Chainstay.




- 11. Insert Frame Dropout Protector into the Rear Dropout.
- 12. Insert Fork Dropout Protector into the Fork Dropout.




- 11. Fold bike in half.


Packing




- 1. Place Suitcase Pad into bottom of suitcase.
- 2. Slide QR Skewers into QR Skewer holders.
- 3. Place Seatpost on the Suitcase Pad with the Saddle on the right side.



- 3. Insert the Handlepost between the Seatstays.
- 4. Place folded bike on top of the Seatpost.
- 5. Fold Suitcase Pad over top of bottom layer components.




- 6. Place Rear Wheel facing downward on right side.
- 7. Fold Suitcase Pad over top of Rear Wheel.




- 8. Place Front Wheel on Suitcase Pad on left side.
- 9. Close the suitcase.



Reassembling the Bike



- 1. Remove and unbag bike components from suitcase.



- 2. Put QR Skewers back in wheels. Remove Frame and Fork Dropout Protectors.
- 3. Unfold the bike.
- 4. Re-fit Wheels.



- 5. Restore Handlepost.
 - 5a. Remove Top Cap.
 - 5b. Connect fork-tube with the Handlepost.
 - 5c. Place the Top Cap in the Handlepost and tighten the Top Cap Bolt to 6-8 Nm.
 - 5d. Make sure the Handlebar and Front Wheel are at right angles.
 - 5e. Tighten the Steerer Clamp Bolts to 10-12 Nm.
- 6. Restore Seatpost.
- 7. Refit pedals.